

Step one:

Unzip the file “a2plus more ver12” and move the folder to your Mod folder in the FreeCAD directory.

Unzip and open the files

Unzip and open the file called named “Assy with broken constraints”.

Select the workbench called “A2plusMore Ver12” from the dropdown.

Hopefully you have the Icons shown to the right.

Click on the green arrow to check the assembly for broken constraints.


If there are broken constraints a dialog box with a list of the broken constraints should appear as shown below.



You can close the box or click the “Open Viewer button to view and change the constraints. See the previous for the viewer instructions.

If you open the viewer with the button, only the broken constraints will be in the viewer table.

Picture of report from the checker.



Picture of viewer list if “Open viewer” button is pressed.

